

Table of Contents

Chapter 1 Introduction	1
Overview.....	1
What's in the Package	2
System Requirements	3
Chapter 2 Hardware Installation and Setup	4
Connection Ports	4
Connecting an IBM PC and VGA Monitor	5
Connecting a Macintosh (or NEC) Computer and Display Monitor	6
Displaying Computer Presentations on TV or Recording to a Videotape	7
Setting up AVerVision DL as a Video Switcher	8
Inserting the Lamp to the AVerVision DL Unit	8
Chapter 3 Using the AVerVision DL	10
Three Presentation Modes	10
VGA Mode	10
Overlay Mode	11
Camera Mode	12
Using the Remote Control	13
Menu Functions	16
VGA Mode	16
Overlay Mode	18
Camera Mode	19
Timer Function	20
Special Highlighting Functions	21
AVerMedia Spot	21
AVerMedia Pointer	23
AVerMedia Spotlight	24
Different Types of Zoom	26
Normal Zoom	26
AVerMedia Area Zoom	26
AVerMedia Spot-Zoom	27
AVerMedia Pointer-Zoom	27
Panning the Zoomed Image	27
Touch Button Control Panel	28
The LED Panel	29

Chapter 4 Troubleshooting.....	30
Appendix Supported Display Modes	32